

Trouble Shooting Instructions

I have an Overcurrent Feedback Top or Bottom Server Server Motor Error

Electric Models that Apply: Phenom 1 & 2

Step	Description	Tools	Picture
	<p>The more common statements regarding Feedback error messages are...</p> <ul style="list-style-type: none"> • “My machine stopped working and the screen says Over Current error.” • “My machine says Over Current Top Server Motor Error.” • “My Machine says Over Current Bot Server Motor Error Elevation Error.” • <p>The most common reason for these error messages are:</p> <ul style="list-style-type: none"> • A Ball Jam in the ball chute in between the server wheels. • A ball inside the inside and around the sweep motor and power supply. 	<p>Phillips Screw Driver</p>	



Trouble Shooting Instructions

I have an Overcurrent Feedback Top or Bottom Server Server Motor Error

	<p>Using your hand through the front of the machine try to feel around past the server wheel assembly as sometimes you will find a tennis ball that has been hit back into the machine.</p> <p>If you do find a ball(s) try to remove them very carefully as they may be tangled underneath fragile wiring.</p> <p>Remove the control panel to get a good look from the rear angle. To remove the control panel you will need a Phillip head screwdriver and remove the 4 black screws. Once removed you will be able to reach inside to feel for balls.</p> <p>If following all of these steps do not resolve the issue please call our technical support team at (800)526-4041 ext. 14.</p>		

How to Order Elite Replacement Parts	Phenom Parts
<p>Website: http://www.lobstersports.com Email: sales@lobstersports.com Phone: 800.526.4041 Fax: 818.764.6061 We accept Visa, MasterCard or Discover & PayPal</p>	<p>Server Motor Part # E872 - \$60.00</p>